

REMPLACEMENT Boitier WatchGuard

Procédure WG - [AP 2023/10]

ETAPE 1 – Récupération de la config du boitier en place

Se connecter sur le Boitier en fonctionnement. Grâce à Policy Manager, récupérer la config sur son PC.

<u>F</u> ic	hier	Modifi <u>e</u> r	Afficher	<u>Configuration</u>	<u>R</u> éseau	FireCl	uster	V <u>P</u> N	Services of	d'abonnem	en <u>t A</u>	ide
	•	Nouveau			Ctr	l+N	¥ ,\$	A 💷	/	E 🔍	?	
	5	<u>O</u> uvrir				>	ices ((includin	ng the Inter	net) to cor	nnect to	your Fire
E		Enregi <u>s</u> trer				>		S <u>u</u> r Fi	rebox		(Ctrl+U
		Sauvegard	er et Resta	urer			Ę	En <u>t</u> ar	nt que fichi	er	(Ctrl+S
		Mettre à niv	ea <u>u</u>				5	Comm	ne sur la <u>V</u> e	ersion	C	Ctrl+V
		<u>G</u> érer les u	tilisateurs e	t les rôles				Toujo	urs créer u	ine sauveg	garde	
		C:\Users\	. \T25-OPTI	CIM-ROANNE-02	.xml				FTP-pro	ху	-	Any-Tru
		C:\Us \T2	5-IBERLUS	-2023-10-18-02	.xml				HTTP-pi HTTPS-	roxy proxy		Any-Tru Any-Tru
		C:\Us \T2	5-IBERLUS	-2023-10-18-01	.xml				WG-Cer	t-Portal	/ Wobl	Any-Tru
		C:\U \M29	0-Mazeno	d-2023-10-18-01	l.xml				DNS	ware-Arr	-vvebi	Any-Tru Any-Tru
		C:\Us \M2	200-ALOTR	A-2023-09-18-0	1.xml				Ping WG-Fire	ebox-Mamt		Any-Tru Any-Tru
—		Quitter							TCP-UD	P		Any-Tru
h				_					Mily			Mily

ETAPE 2 – Ajouter le nouveau boitier sur l'interface client WatchGuard

Se connecter au portail <u>www.watchguard.com</u> avec les identifiants du client (voir fiche info).

Si des licences supplémentaires sont nécessaires (par ex : APT-blocker), les rajouter de la même manière.

Nb : Si une demande de changement de mot de passe apparait, la faire et <u>bien renseigner le</u> nouveau mot de passe dans la fiche info

Une fois le boitier ajouté correctement avec toutes ses licences, télécharger les clefs (Feature Key) dans :

My WatchGuard > Manage Products > Network Security

Enregistrer dans un fichier texte, cela nous servira plus tard.





MY WATCHGUARD
Activate Products

Download Software Recent Activations WatchGuard Cloud Manage Cases Manage DNSWatch Manage Products Manage Profile Manage Users

Fireb	oxes WatchGuard S	ystem Manager 🛛 🛛 🛛	DR Core
ACTIVATE PRODU	CI.		
nter a serial number, fri	endly name, or model to filter th	e list	٥
Friendly Name	Sərial Number	Support Explicat	Ion
T25-IBERLUS	D02C0331E-0A36	Oct 11, 2028	
	items per page	x 25 🔻 1 1 of 1	GET FEATURE KEY
			RENAME DEVICE
			RETIRE DEVICE

Démarrer puis connecter le boitier de cette

#ETH0 = Réseau avec accès internet

#ETH1 = Un PC en DHCP

Connect Your Firebox and Power it On

Make sure your computer is configured to use DHCP. When you connect to the Firebox, it will assign an IP address on the **10.0.1.0/24** network.





WatchGuard Fireware Web UI

Welcome to the Web Setup Wizard

Select a Configuration Method

- New Configuration Create a new local configuration for your Firebox. You can add the Firebox to WatchGuard Cloud for monitoring od m
- Cloud-Managed Establish a connection to WatchGuard to download a configuration created in WatchGuard Cloud.
 RapidDeploy Establish a connection to WatchGuard to download a configuration created for RapidDeploy.

 Backup Image Restore a configuration from a saved backup image.

Read the License Agreement

I accept the End User License Agreement

More Information

Se connecter ensuite au Web UI sur https://10.0.1.1:8080

Login : ***** Password : *****

manière;

Choisir « New Configuration ».

		ine mes or	
Welcome	to the Web Setu	ıp Wizard	
Good news	s! Your Firebox is o	nline and activa	ted
By default, your choose to config	Firebox uses DHCP to get a gure the external interface of	in IP address for the ex with other network sett	ternal interface. You can also ings.
Keep the def	ault DHCP external interfac	e settings	
O Contigure th	e external interface setting		
			BACK
1000			
Watch	Guard	Fireware Web	IL
		111001-00-0	
Configu	re the DNS an	a WINS Ser	vers
Add the addr	ess information for yo	ur DNS and WINS se	ervers. Your Firebox uses these addresse
resolve name	es to IP addresses for D	HCP clients and sor	ne Fireware features.
Domain Nam	10		
DNS Servers			
WINS Servers	5		
WatchG	uard F	ireware Web U	1
WatchG	uard F	ireware Web U	I
Configur	iuard F	ireware Web U Interface	1
Configur Type an availa	iuard F re the Trusted ible IP address from yo	ireware Web U Interface ur internal, private i	l network to use for the trusted interface.
Configur Type an availa IP address ber	ward F the Trusted ible IP address from yo comes the trusted inter	ireware Web U Interface ur internal, private r face address.	I network to use for the trusted interface.
Configur Type an availa IP address bee	iuard F ie the Trusted ible IP address from yo comes the trusted inter 10.0.1.1	ireware Web U Interface ur internal, private r face address.	l network to use for the trusted interface. T
Configur Type an availa IP address ber IP Address [] C Enable the IP Address Ra	ward F re the Trusted able IP address from yo comes the trusted inter 10.0.1.1 EDHCP server on this in nize	Ireware Web U Interface ur internal, private r face address. / 24 iterface	network to use for the trusted interface.
Configur Type an availa IP address ber IP Address E IP Address Ra Start	tuard F the Trusted to the Trusted to the trusted inter 10.0.1.1 DHCP server on this in nge	ireware Web U Interface ur internal, private r face address. / 24 iterface	l network to use for the trusted interface.
Configur Type an availa IP address bed IP Address Ra Start End	ivard F re the Trusted address from yo comes the trusted inter 10.0.1.1 F DHCP server on this in nge 10.0.1.2	ireware Web U Interface ur internal, private r face address. / 24 iterface	l network to use for the trusted interface. T
Configur Type an availa IP address ber IP Address Ra IP Address Ra Start End	ivand F re the Trusted ible IP address from yo comes the trusted inter 10.0.1.1 t DHCP server on this in rige 10.0.1.2 10.0.1.254	Ireware Web U Interface ur internal, private / face address. / 24 iterface	network to use for the trusted interface. T
Configur Type an availa IP address ber IP Address Ra IP Address Ra Start End If you change Fireware Web computer is in	ivard F re the Trusted ible IP address from yo comes the trusted inter 10.0.1.1 # DHCP server on this in nge 10.0.1.2 10.0.1.254 the trusted interface IP UI after you finish the in the same subnet as th	Interface ur internal, private r face address. / 24 iterface address, you must al e IP address for this	L network to use for the trusted interface. T
Configur Type an availa IP address ber IP Address Ra IP Address Ra Start End If you change Fireware Web computer is in	ivard F re the Trusted able IP address from yo comes the trusted inter 10.0.1.1 E DHCP server on this in rige 10.0.1.2 10.0.1.254 the trusted interface IP UI after you finish the inte same subnet as the	Ireware Web U Interface ur internal, private / face address. / 24 iterface / 24 iterface address, you must ak wizard, You must ak e IP address for this	Letwork to use for the trusted interface. T

Laisser en DHCP l'interface externe (#ETH0)

Renseigner les DNS 8.8.8.8 et 1.1.1.1

Laisser l'interface #ETH1 par défaut : 10.0.1.1/24

Configurer les identifiants *status* et *admin* <u>avec les mêmes que ceux de l'ancien</u> <u>boitier.</u>

Récupérer les infos dans la fiche client.

Create Passphrases for your Firebox Your Prebox includes two default user accounts: dimin - read-write privileges: Status - read-write privileges: Confirm passphrase rouse write dech account; Confirm passphrase: Configure: Passphrase: Configure: Configure: Configure: Configure: Configure: Configure: Configure: Configure: Configure: Configure:		FILEWALE WED OI
Your Pirebox includes two default user accounts: Implie - read-only privileges: Type the passphrase to use with each account. Exchanges remain contain between 8 and 32 characters. User name status (read-only) Passphrase	Create Pass	phrases for your Firebox
admin - read-write privileges. Type the passphrase to use with each acount. Each passphrase must contain between 8 and 32 characters. User name status (read-only) Passphrase	Your Firebox include	es two default user accounts:
Type the passphrase must contain between 8 and 32 characters. User name status (read-only) Passphrase	admin — read-wr status — read-on	te privileges. y privileges.
User name status (read-only) Passphrase	Type the passphras Each passphrase m	e to use with each account. Ist contain between 8 and 32 characters.
Passphrase	User name	status (read-only)
Confirm passphrase admin (read-write) Passphrase admin (read-write) Passphrase admin (read-write) Passphrase admin (read-write) Confirm passphrase admin (read-write) Configure Contact Management Tomanage your Firebox to be managed from a remote computer Remote Computer IP Address Address address you specify is added to the peadlows you people is added to the peadlow connections from your remote computer. Configure Contact and Feedback Settings Contact Information pauly for the firebox to be readed from a bey poul identify your Firebox when you manage your remote computer. Configure Contact and Feedback Settings Contact Information pauly people wide firebox is used, but does not indiget formation in the reson Pavice Feedback To address you your Firebox is used, but does not indiget formation about how your Firebox is used, but does not indiget formation about how your Firebox is used, but does not indiget formation in the reson Device Feedback Pavice Feedback helps WatchGuard improve products and features. The feedback that your F	Passphrase	********
User name admin (read-write) Passphrase Centirm passphrase Centi	Confirm passphrase	· ·····
Passphrase Centirm passphrase Centirm passphrase Centirm passphrase Center lange your Firebox from a remote network, select the option and specify the IP address of temate computer Computer IP Address Center Computer IP Address Center Computer IP Center Center IP Ce	User name	admin (read-write)
Confirm passphrase Image: Sector	Passphrase	
	Confirm passphrase	
The default configuration on your Firebox automatically includes the WatchGuard policy. This p allows you to connect to and manage your Firebox from a computer on the trusted or optional networks. When you enable remote management, the IP address you specify is added to the pc allow connections from your remote computer.	Enable Rem To manage your Fire remote computer.	box from a remote network, select the option and specify the IP address to be managed from a remote computer uputer IP Address
Fireware Web UI Configure Contact and Feedback Settings contact Information betify the information for this Firebox. This helps you identify your Firebox when you manaultiple devices. evice Name evice Location betify the endowned evice Feedback evice Feedback evice Feedback evice Feedback evice feedback helps WatchSuard improve products and features. The feedback that your Finds to WatchGuard includes information about how your Firebox is used, but does not incleating information about your company or your company data. Send device feedback to WatchGuard	The second was made	
Fireware Web UI Configure Contact and Feedback Settings Contact Information pecify the information for this Firebox. This helps you identify your Firebox when you manapultiple devices. Vevice Name Image: Setting Seting Setting Setting Setting Setting Seting Setting S	allows you to conne networks. When you allow connections fr	t to and manage your Firebox from a computer on the trusted or optic enable remote management, the IP address you specify is added to th om your remote computer.
Fireware Web UI Configure Contact and Feedback Settings Contact Information perify the information for this Firebox. This helps you identify your Firebox when you manapultiple devices. Vevice Name TB0 Levice Location Contact Person Device Feedback Vevice Feedback uevice information about your company or your company data. Send device feedback to WatchGuard	allows you to conne networks. When you allow connections fr	t to and manage your Firebox from a computer on the trusted or optio enable remote management, the IP address you specify is added to th om your remote computer.
Fireware Web UI Configure Contact and Feedback Settings Contact Information pecify the information for this Firebox. This helps you identify your Firebox when you manapultiple devices. Device Name Table Vervice Name Table Device Feedback Vervice Feedback Vervice Feedback Vervice Feedback Tertifying information about your company or your company data. Send device feedback to WatchGuard	allows you to conne networks. When you allow connections fr	t to and manage your Firebox from a computer on the trusted or optic enable remote management, the IP address you specify is added to th om your remote computer.
Fireware Web UI Configure Contact and Feedback Settings Contact Information pecify the information for this Firebox. This helps you identify your Firebox when you manapultiple devices. bevice Name I device Location I contact Person Device Feedback bevice Feedback NatchGuard improve products and features. The feedback that your Firebox is used, but does not incleated for WatchGuard includes information about how your Firebox is used, but does not incleated for the feedback to WatchGuard 2 Send device feedback to WatchGuard Send device feedback to WatchGuard	allows you to conne networks. When you allow connections fr	t to and manage your Firebox from a computer on the trusted or optic enable remote management, the IP address you specify is added to th om your remote computer.
WatchGuard Fireware Web UI Configure Contact and Feedback Settings Contact Information pecify the information for this Firebox. This helps you identify your Firebox when you manapultiple devices. Device Name TB0 Device Location Contact Person Device Feedback Device Feedback Herice Feedback helps WatchGuard improve products and features. The feedback that your Firebox is used, but does not incluse information about your company of your company data. 2 Send device feedback to WatchGuard	allows you to conne networks. When you allow connections fr	t to and manage your Firebox from a computer on the trusted or optic enable remote management, the IP address you specify is added to th om your remote computer.
Configure Contact and Feedback Settings Contact Information pecify the information for this Firebox. This helps you identify your Firebox when you manage nultiple devices. Pevice Name TB0 I Pevice Location Contact Person Device Feedback revice Feedback revice Feedback revice feedback helps WatchGuard improve products and features. The feedback that your F reds to WatchGuard includes information about how your Firebox is used, but does not ind lentifying information about your company data. Send device feedback to WatchGuard	allows you to come networks. When you allow connections fr	t to and manage your Firebox from a computer on the trusted or optic enable remote management, the IP address you specify is added to th om your remote computer.
Contact Information pecify the information for this Firebox. This helps you identify your Firebox when you mana nultiple devices. Device Name T80 T80 Device Location Contact Person Device Feedback levice Feedback levice Feedback helps WatchGuard improve products and features. The feedback that your Fi rebox is used, but does not incl tentifying information about your company or your company data. Send device feedback to WatchGuard	allows you to come networks. When you allow connections fr	t to and manage your Firebox from a computer on the trusted or optic enable remote management, the IP address you specify is added to th om your remote computer.
Contact Information pecify the information for this Firebox. This helps you identify your Firebox when you mana nultiple devices. Evvice Name TBO I Device Location Contact Person Device Feedback Evice feedback helps WatchGuard improve products and features. The feedback that your F ends to WatchGuard includes information about how your Firebox is used, but does not incl fentifying information about your company or your company data. Send device feedback to WatchGuard	Allowis you to come networks. When you allow connections fr	t to and manage your Firebox from a computer on the trusted or optic enable remote management, the IP address you specify is added to th om your remote computer.
pecify the information for this Firebox. This helps you identify your Firebox when you mana nultiple devices. Pevice Name TB0 I Pevice Location Contact Person Device Feedback revice Feedback helps WatchGuard improve products and features. The feedback that your Firebox is used, but does not incle infitying information about your company or your company data. Send device feedback to WatchGuard	Milows you to come networks. When you allow connections fr MatchGuard Configure Co	t to and manage your Firebox from a computer on the trusted or optic enable remote management, the IP address you specify is added to th om your remote computer.
Tablevice Name Tablevice Location Contact Person Device Feedback revice Feedback revice feedback helps WatchGuard Improve products and features. The feedback that your F reds to WatchGuard Includes information about how your Firebox is used, but does not incl fentifying information about your company of your company data. Send device feedback to WatchGuard	allows you to come networks. When you allow connections fr Configure Co Configure Co	t to and manage your Firebox from a computer on the trusted or optic enable remote management, the IP address you specify is added to th om your remote computer.
Device Name TB0 I Device Location I Contact Person I Device Feedback I revice feedback helps WatchGuard improve products and features. The feedback that your F rends to WatchGuard includes information about how your Firebox is used, but does not includes information about your company data. 2 Send device feedback to WatchGuard	allows you to come networks. When you allow connections fr Configure Co Configure Co Contact Inform pecify the informati	t to and manage your Firebox from a computer on the trusted or optic enable remote management, the IP address you specify is added to th om your remote computer.
Device Location Contact Person Device Feedback levice feedback helps WatchGuard improve products and features. The feedback that your F ends to WatchGuard includes information about how your Firebox is used, but does not incl fentifying information about your company or your company data. Send device feedback to WatchGuard	allows you to come networks. When you allow connections fr WatchGuard Configure Co Contact Inform pecify the informati nultiple devices.	t to and manage your Firebox from a computer on the trusted or optic enable remote management, the IP address you specify is added to th om your remote computer.
Contact Person Device Feedback levice feedback helps WatchGuard improve products and features. The feedback that your F ends to WatchGuard includes information about how your Firebox is used, but does not incl lentflying information about your company or your company data. Send device feedback to WatchGuard	allows you to come networks. When you allow connections fr Configure Co Configure Co Contact Inform pecify the informati nultiple devices.	t to and manage your Firebox from a computer on the trusted or optic enable remote management, the IP address you specify is added to tho om your remote computer.
Device Feedback evice feedback helps WatchGuard improve products and features. The feedback that your F ends to WatchGuard includes information about how your Firebox is used, but does not incl fentifying information about your company or your company data. Send device feedback to WatchGuard	allows you to come networks. When you allow connections fr allow connections fr Configure Co Configure Co Contact Inform pecify the informati nultiple devices. Zevice Name	t to and manage your Firebox from a computer on the trusted or optic enable remote management, the IP address you specify is added to th om your remote computer.
evice feedback helps WatchGuard improve products and features. The feedback that your F ends to WatchGuard includes information about how your Firebox is used, but does not incl fentifying information about your company or your company data. Send device feedback to WatchGuard	allows you to come networks. When you allow connections fr Configure Co Contact Inform pecify the informati rultiple devices. Nevice Name	t to and manage your Firebox from a computer on the trusted or optic enable remote management, the IP address you specify is added to tho om your remote computer.
2 Send device feedback to WatchGuard	Allows you to come networks. When you allow connections fr Configure Co Configure Co Contact Inform pecify the informati nultiple devices. Device Name Device Location Contact Person	t to and manage your Firebox from a computer on the trusted or optic enable remote management, the IP address you specify is added to tho om your remote computer.
	allows you to come networks. When you allow connections fr Configure Co Contact Inform pecify the information ultiple devices. Device Name Contact Person Device Feedback help Device Feedback help Device Feedback help Device Feedback help Device Feedback help	t to and manage your Firebox from a computer on the trusted or optic enable remote management, the IP address you specify is added to th om your remote computer. Fireware Web UI Intact and Feedback Settings hation an for this Firebox. This helps you identify your Firebox when you m I Ack s WatchGuard improve products and features. The feedback that you includes information about how your Firebox is used, but does not an about your company or your company data.
	Allows you to come networks. When you allow connections fr allow connections fr Configure Co Configure Co Contact Information Device Name Device Location Contact Person Device Feedback help ends to WatchGuard fentifying informatic Send device feed	t to and manage your Firebox from a computer on the trusted or optic enable remote management, the IP address you specify is added to the om your remote computer. Fireware Web UI Intact and Feedback Settings hation an for this Firebox. This helps you identify your Firebox when you m I I Ack s WatchGuard improve products and features. The feedback that you includes information about how your Firebox is used, but does not in about your company or your company data. back to WatchGuard
	Allows you to come networks. When you allow connections fr Configure Co Configure Co Contact Inform pecify the information Device Name Sevice Location Contact Person Device Feedback help ends to Watch Guard Jentice feedback help ends to Watch Guard Jentifying information Contact Person	t to and manage your Firebox from a computer on the trusted or optic enable remote management, the IP address you specify is added to the om your remote computer. Fireware Web UI Intact and Feedback Settings hation an for this Firebox. This helps you identify your Firebox when you m Intact and Feedback and features. The feedback that yo ack s WatchGuard improve products and features. The feedback that yo includes information about how your Firebox is used, but does not in about your company or your company data. Sack to WatchGuard

Ne pas configurer cette partie.

Device Name : BOITIER-CLIENT (Exemple : « T80-NOM »)

Device Location : CODE-POSTAL VILLE (Exemple : « *13005 Marseille* »)

Contact Person : « ***** »

Device Feedback : Décocher.

Watch	Guard F	Fireware Web UI	
Select t	he Time Zone		
Select the tir that appear	ne zone where your Firel in the log messages and	abox is located. The time zone setting controls the date and time I reports for your Firebox.	
Time Zone	(GMT-05:00) Indiana (E	East) 🖌	

Subscription Se	rvices
Your Firebox feature key is these subscription service	ncludes these Subscription Services. The wizard will automatically ena s with recommended security settings:
🗸 Gateway AntiVirus —	Drops HTTP and FTP connections when a virus is detected
Intrusion Prevention 5	ervice — Drops connections identified as a network exploit
Application Control —	Drops traffic from risky applications
🖌 Reputation Enabled D	efense — Blocks traffic from botnet sites and other hostile sites
🖌 APT Blocker — Identif	ies and drops connections associated with advanced malware
The wizard will also enable	e WebBlocker. Next, select the WebBlocker content categories to den

Select WebBlocker Categories

WebBlocker can deny outgoing connections to malicious websites and other risky web content. We recommend that you deny these content categories:

- Security (Malware, Bot Network, Spyware, Malicious and other subcategories)
- Extended Protection (Emerging Exploits, Suspicious Content, and other subcategories)
- Proxy Avoidance 🗹 Parked Domain

Select other common website categories to deny:

- Adult Material (Nudity, Adult Content, Sex)
- Gambling
- Intolerance
- Tasteless
- U Violence

After you finish the wizard, you can edit the WebBlocker configuration to deny additional content categories.

Faire Next

Configurer la bonne time zone.

Faire Next également

(Tout paramétrage est inutile car on va tout « écraser » en réinjectant la config)

Le dernier écran est simplement un récap de tout ce qu'on a configurer.

Vérifier les infos et faire Next.

Le boitier est maintenant initialisé.

WatchGuard	Fireware Web UI
Summary	
You have selected these config	uration settings:
Activation Feature Key External Interface Domain Name DNS Servers WINS Servers Trusted Interface Remote Host IP Address Device Name Device Location Contact Person Time Zone WebBiocker Gateway AntiVirus Intrusion Prevention Application Control RED	Succeeded Retrieved DHCP — Get an IP address automatically watchguard.kl 8.8.8.8 None 10.10.127.1/24 — DHCP server enabled None — Remote management disabiled Firewalls.com Indianapolis IT Closet Alan Steady (GMT-05:00) Indiana (East) Enabled Enabled Enabled Enabled Enabled Enabled with feedback, includes Both Detection Enabled
To apply these settings, click Next	L
	BACK

ETAPE 4 – Injecter la configuration

Sur WatchGuard System Manager (à télécharger sur <u>www.watchguard.com</u>), ouvrir le Policy Manager.

Ouvrir le fichier de config préalablement récupéré à l'étape1

<u>F</u> ichier	Modifier	Afficher	<u>Configuration</u>	<u>R</u> éseau	Fi <u>r</u> eClu	ister	V <u>P</u> N	Service	s d'abor	ineme	in <u>t</u> z	<u>A</u> ide
▶	<u>N</u> ouveau			Ctr	I+N	¥ #		F 6) 🖂	Q	?	
⊵	<u>O</u> uvrir				>	<u></u>	<u>F</u> irebo	ж		C)trl+F	;
	Enregi <u>s</u> trer				>	Þ	Fi <u>c</u> hie	r de cor	figuratio	on C	Ctrl+ (D
	<u>S</u> auvegarde	er et Restau	urer									
	Mettre à niv	ea <u>u</u>				_						
	Gérer les ut	ilisateurs e	t les rôles					-	Type de	straté	nie	
	C:\Users\	\T25-OPTI	CIM-ROANNE-02	2.xml				FTP-	огоху			A
	C:\Us \T2	5-IBERLUS	-2023-10-18-02	.xmi				HTTP	-proxy S-proxy			A A
	C:\Us \T2	5-IBERLUS	-2023-10-18-01	.xml				WG-	Cert-Port	tal		A
	C:\U \M29	0-Mazenoo	1-2023-10-18-01	1.xml				DNS	-ireware	e-X1M	-wet	A IU A
	C:\Us \M2	00-ALOTR	A-2023-09-18-0)1.xml				Ping				A
	<u>Q</u> uitter							TCP-I Any	UDP	wymt		A

R Configuration	du périphérique	×
Modèle Firebox :	Firebox T Series V T25 V	
Nom :	T25-XXXX	
Emplacement :	13ххх - хххххххх	
Contact :	ALTEA	
Fuseau horaire :	(GMT+01:00) Amsterdam, Copenhague, Madrid, Paris, Vilnius \qquad \sim	
	QK Annuler Aide	

Modifier les paramètres de périphérique avec les bonnes infos du nouveau boitier : **Configuration > Système**

Configuration > Clef de fonctionnalités

Vérifier que la licence soit opérationnelle.

Si ce n'est pas le cas, importer le fichier de licences (récupéré à l'étape 2) dans le boitier.

Résumé					Impor	rter
Mard Mark	705				TA14	
Modele : Numéro de série :	125				Tel	er
Version du logiciel :	Le Système d'Exploitatio	n Fireware OS				
Signature :	302E0215037C6EC3-F3	22CF95B84B5796	-1D22DD0E20D	A9890-7502150		
- Fonctionnalitáe						
Tonctionnaites				A		
Fonctionnalité		Valeur	Expiration	Etat		
Access Portal		Illimite	2026 Oct 19	1091 jours		
APT Blocker	101	Illimité	2026 Oct 19	1091 jours		
Gateway AntiVir	rus (AV)	Illimité	2026 Oct 19	1091 jours		
Cloud Connect		Illimité	2026 Oct 19	1091 jours		
Cloud Visibility		Illimité	2026 Oct 19	1091 jours		
J Dimension Basic		Illimité	2026 Oct 19	1091 jours		
J Dimension Comm	nand	Illimité	2026 Oct 19	1091 jours		
DNSWatch		Illimité	2026 Oct 19	1091 jours		
IntelligentAV		Illimité	2026 Oct 19	1091 jours		
Intrusion Prevent	tion (IPS)	Illimité	2026 Oct 19	1091 jours		
LiveSecurity Ser	vice	Illimité	2026 Oct 19	1091 jours		
Découverte de r	éseau	Illimité	2026 Oct 19	1091 jours		
Reputation Enabl	led Defense	Illimité	2026 Oct 19	1091 jours		
spamBlocker		Illimité	2026 Oct 19	1091 jours		
Assistance		Illimité	2026 Oct 19	1091 jours		
Threat Detection	& Response	Illimité	2026 Oct 19	1091 jours		
 Activer la synchron Envoyer une notifica (Fireware OS v11.1) 	isation automatique de clé de ation d'alerte lorsqu'une clé de 0.1 et versions ultérieures)	fonctionnalité (Fire fonctionnalité est	eware OS v11.6 t sur le point d'e	5.3 et versions u xpirer ou a expir	ltérieures) ·é <u>N</u> otification	ns
 Activer la synchron Envoyer une notifica (Fireware OS v11.1 	isation automatique de clé de ation d'alerte lorsqu'une clé de 0.1 et versions ultérieures)	fonctionnalité (Fire fonctionnalité est	eware OS v11.6 t sur le point d'e	3 et versions ul xpirer ou a expir	ltérieures) 'é <u>N</u> otificatio	ns
 Activer la synchron Envoyer une notifica (Fireware OS v11.1 	isation automatique de clé de ation d'alerte lorsqu'une clé de 0.1 et versions ultérieures)	fonctionnalité (Fire	eware OS v11.6 t sur le point d'e	3.3 et versions ul xpirer ou a expir <u>Q</u> K	ttérieures) ré <u>N</u> otificatio	ns Aide
Activer la synchron Envoyer une notific: (Fireware OS v11.1	isation automatique de clé de ation d'alerte lorsqu'une clé de 0.1 et versions ultérieures) er <u>C</u> onfiguration <u>R</u> é	fonctionnalité (Fire fonctionnalité est esseau Fi <u>r</u> eC Ctrl+N	eware OS v11.6 t sur le point d'e luster V <u>P</u> I	A Services	Itérieures) ré <u>Notification</u> Annuler d'abonneme) P Q	Aide
Activer la synchron Envoyer une notific: (Fireware OS v11.1 Modifi <u>er</u> <u>A</u> ffiche <u>N</u> ouveau <u>Q</u> uvrir	isation automatique de clé de ation d'alerte lorsqu'une clé de 0.1 et versions ultérieures) er <u>C</u> onfiguration <u>R</u> é	fonctionnalité (Fire 6 fonctionnalité est 2 seau FireC 2 Ctrl+N >	eware OS v11.6 t sur le point d'e luster VPI	A et versions ul xpirer ou a expir QK A Services Q E A uding the Inte	Annuler d'abonneme)	Aide
Activer la synchron Envoyer une notific: (Fireware OS v11.1 Modifi <u>er A</u> ffiche gouveau <u>2</u> uvrir Enregistrer	isation automatique de clé de ation d'alerte lorsqu'une clé de 0.1 et versions ultérieures) er <u>C</u> onfiguration <u>R</u> é	fonctionnalité (Fire of fonctionnalité est èsseau Fi <u>r</u> eC: Ctrl+N >	eware OS v11.6 Isur le point de	A set versions ul xpirer ou a expir QK Services Services uding the Inte r Firebox	tiérieures) é <u>Notification</u> Annuler a d'abonneme) P Q ernet) to con	Aide
Activer la synchron Envoyer une notific: (Freware OS v11.1 Modifi <u>er</u> <u>A</u> fficher <u>d</u> ouveau <u>2uvrir Enregigtrer <u>Sauvegarder et Res</u> </u>	isation automatique de clé de ation d'alerte lorsqu'une clé de 0.1 et versions utérieures) er <u>C</u> on figuration <u>Ré</u> ataurer	fonctionnalité (Fire e fonctionnalité est esseau FireC Ctrl+N > >	Iuster VP	.3 et versions ul xpirer ou a expir QK QK N Services Image:	Annuler a d'abonneme) C a con hier	ns Aide ant Aide ant Aide ant Ctrl+U Ctrl+S
Activer la synchron Envoyer une notific: (Fireware OS v11.1 Modifi <u>er</u> <u>A</u> ffiches Jouveau 2uvrir Enregigtrer Sauvegarder et Res Mettre à nivea <u>u</u>	isation automatique de clé de ation d'alerte lorsqu'une clé de 0.1 et versions ultérieures) er <u>C</u> onfiguration <u>R</u> é staurer	fonctionnalité (Fire 6 fonctionnalité est 6 seau FireC Ctrl+N > >	eware OS v11.6 t sur le point d'e luster VPI ces (incli En En Co	A et versions ul xpirer ou a expir X Services Services Services A Services A Services	tiérieures) ré <u>Notification</u> Annuler a d'abonneme a d'abonneme a d'abonneme biernet) to con hier ⊻ersion	Aide Aide Aide Ctrl+U Ctrl+S Ctrl+V
Activer la synchron Envoyer une notific: (Fireware OS v11.1 (Fireware OS v11.1 Modifi <u>er A</u> ffiche 40uveau 20vrir Enregigtrer Sauvegarder et Res Mettre à nivea <u>u</u> 2érer les utilisateur	isation automatique de clé de ation d'alerte lorsqu'une clé de 0.1 et versions ultérieures) er <u>C</u> onfiguration <u>Ré</u> staurer s et les rôles	fonctionnalité (Fire o fonctionnalité est èsseau Fi <u>r</u> eC Ctrl+N >	eware OS v11.6 t sur le point de luster VP ces (inclu Es Su Su En En Co To	A Services Serv	tiérieures) ·é <u>Notification</u> Annuler · d'abonneme · d	ns Aide Aide Aide Ctrl+U Ctrl+S Ctrl+V arde
Activer la synchron Envoyer une notific: (Fireware OS v11.1 Modifier <u>A</u> ffiche jouveau <u>2uvrir inregistrer sauvegarder et Ress Mettre à niveau <u>2</u>érer les utilisateure ::\Users\\T25-OI </u>	isation automatique de clé de ation d'alerte lorsqu'une clé de 0.1 et versions utérieures) er <u>Configuration</u> <u>Ré</u> staurer s et les rôles PTI/CIM-ROANNE-02.xm	fonctionnalité (Fire eseau FigeC Ctrl+N >	Iuster VP	A Services Serv	Annuler a d'abonneme a d'abonneme b l l l l l l l l l l l l l l l l l l l	ns Aide Aide Ctrl+U Ctrl+S Ctrl+V arde Any-1
Activer la synchron Envoyer une notific: (Fireware OS v11.1 Modifi <u>er</u> <u>A</u> fficher Jouveau 20vrir inregigtrer Sauvegarder et Res Aettre à nivea <u>u</u> 2érer les utilisateur C:Wsers\\T25-DI C:Ws\T25-BERLİ	isation automatique de clé de ation d'alerte lorsqu'une clé de 0.1 et versions ultérieures) er <u>C</u> onfiguration <u>Ré</u> ataurer s et les rôles PTICIM-ROANNE-02.xm US-2023-10-18-02.xm	fonctionnalité (Fire of fonctionnalité est esseau FireC Ctrl+N > >	eware OS v11.6 t sur le point de luster VP ces (incl 5 5 5 6 7 0 7 0	A Services A Services A Services J Services J Services A Services J Serv	tiérieures) *é Notification Annuler a d'abonneme a d'a	Aide Aide Aide Ctrl+U Ctrl+S Ctrl+V arde Any-T Any-T Any-T
Activer la synchron Envoyer une notific: (Fireware OS v11.1 Modifi <u>er A</u> ffiche Mouveau Quvrir Enregigtrer Sauvegarder et Res Mettre à nivea <u>u</u> Gérer les utilisateur: C:\Users\\T25-IBERLI C:\Use\T25-IBERLI C:\Us\T25-IBERLI C:\Us\T25-IBERL	isation automatique de clé de ation d'alerte lorsqu'une clé de 0.1 et versions ultérieures) er <u>C</u> onfiguration <u>Ré</u> itaurer s et les rôles PTICIM-ROANNE-02.xm US-2023-10-18-01.xm	fonctionnalité (Fire of fonctionnalité est èsseau FireC: Ctrl+N > >	eware OS v11.6 sur le point de luster VP ces (inclu Su Co To	A Services Serv	tiérieures) é Notification Annuler a d'abonneme a d'ab	ns Aide Aide Ctrl+U Ctrl+V arde Any-1 Any-1 Any-1
Activer la synchron Envoyer une notific: (Fireware OS v11.1 Modifier Affiche Jouveau 20vrir Enregigtrer Sauvegarder et Res Acttre à niveau 2érer les utilisateur: 2:(Uss, \T25-IBERLI 2:(Us, \T25-IBERLI 2:(Us, \T25-IBERLI 2:(U, \M290-Maze)	isation automatique de clé de ation d'alerte lorsqu'une clé de 0.1 et versions utérieures) er <u>Configuration Ré</u> staurer s et les rôles PTICIM-ROANNE-02.xm US-2023-10-18-01.xm nod-2023-10-18-01.xm	fonctionnalité (Fire seau FireC) Ctrl+N > 11 11 1	Iuster VP	A Services Serv	tiérieures) é <u>Notificatio</u> Annuler a d'abonneme a d'a	ns Aide ant Aide ant Ctrl+U Ctrl+V arde Any-1 Any-1 Any-1 L-WebUI Any-1 Any-1
Activer la synchron Activer la synchron Chrower of synchron Chrower of synchron Chrometer of the synchro Chrometer of the synchron Chrometer of the s	isation automatique de clé de ation d'alerte lorsqu'une clé de 0.1 et versions ultérieures) er <u>C</u> onfiguration <u>Ré</u> staurer s et les rôles PTICIM-ROANNE-02.xm US-2023-10-18-02.xm US-2023-10-18-01.xm nod-2023-10-18-01.xm	fonctionnalité (Fire c fonctionnalité est c fonctionnalité est	Inster VP	A Services A Serv	tiérieures) é <u>Notification</u> Annuler a d'abonneme a d'	Aide Aide Aide Ctrl+U Ctrl+V Ctrl+V arde Any-1

Enregistrer ensuite la config sur le boitier Fichier > Enregistrer > Sur Firebox

ETAPE 5 – Paramétrages spécifiques et vérifications

Faire les paramétrages spécifiques au client et faire des tests pour valider le fonctionnement.

Par exemple (liste non exhaustive, à adapter à la situation) :

Si dans la box du client il y a une réservation DHCP • avec l'adresse MAC du WatchGuard → Renseigner l'adresse MAC du nouveau WatchGuard (eth0) et vérifier qu'il prenne la bonne IP.

WG-Firebox-Mgmt

TCP-UDP

Any

Any-Tri

Any-Tri

Any

- Si le client a un VPN externe SSL, vérifier en partage • de connexion que cela fonctionne.
- Si le client a un VPN IPsec, vérifier que le lien soit bien monté.
- Vérifier que les utilisateurs aient bien accès à internet • et à leur serveur.
- Vérifier que le serveur ait bien accès • internet/anydesk.
- Se connecter sur le nouveau boitier et vérifier que • tout soit ok (pas d'erreur de licences par exemple)
- Si le boitier était accessible à distance, vérifier que • cela fonctionne.
- Etc...

Quitter

Contexte

J'ai utilisé cette procédure pour faire le remplacement du WatchGuard qui est arrivé à expiration dans une entreprise, le WatchGuard sert de pare-feu avec un filtrage qui permet de bloquer une partie des malwares, ransomwares, fishing par email et il permet un control sur la navigation des utilisateurs de l'entreprise. Il peut etre configurer pour ouvrir un tunnel sécurisé entre le réseau de l'entreprise et l'extérieur : le VPN.